

VR Series Power Conversion Modules

Overview:

The unit converts a 24VAC and/or 24VDC input into a regulated 5VDC or 12VDC output.

Reference Chart:

Altronix Model Number	Input	Output	Battery Charging	Cable Assembly	Screw Terminal	Spring Terminal
VR1	24VAC/20VA or higher / 24VDC	12VDC @ 1A max.	-	\checkmark	_	_
VR1T	24VAC/20VA or higher / 24VDC	12VDC @ 1A max.	_	_	_	\checkmark
VR2T	24VAC/20VA or higher / 24VDC	12VDC @ 0.5A max.	_	_	_	\checkmark
VR3T	24VDC	12VDC @ 2A max.	_	_	\checkmark	_
VR4T	24VDC	12VDC @ 3A max.	-	_	\checkmark	_
VR5T	24VAC/50VA or higher / 24VDC	12VDC @ 3A max.	-	_	_	\checkmark
VR5BT	24VAC/50VA or higher / 24VDC	12VDC @ 3A max.	\checkmark	_	_	\checkmark
VR1TM5	16VAC/24VAC/20VA or higher /12 or 24VDC	5VDC @ 1A max.	-	_	_	\checkmark

Agency Listing:

• CE European Conformity.

Input:

• Input 24VAC or 24VDC.

Output:

- 5VDC (VR1TM5) or 12VDC output.
- Filtered and electronically regulated output.
- Built-in overload protection.

Applications:

• Power for 12VDC CCTV cameras and accessories, Fiber Optic Transmitters, REX PIRs, Prox Readers, etc.

Specifications:

C | Visual Indicators:

• Power LED indicator.

Features:

- Modular connector/cable assembly facilitates ease of wiring.
- Compact design allows for integration in a wide range of camera housings.

Dimensions (W x D x H approx.): VR5T and VR5BT:

3.375" x 2.5" x 1.125" (85.7mm x 63.5mm x 28.6mm)

All other units:

1.625" x 2.375" x 1" (41.3mm x 60.3mm x 25.4mm)


Installation Instructions:

Installing VR1 (Fig. 1, pg. 1):

- 1. Mount unit in proximity to the device. Affix one side of velcro (supplied) to the unit and place the second side of the velcro in the desired location.
- 2. Connect Yellow lead and Purple lead to 24VAC transformer or 24VDC power source*.
- 3. Measure output voltage and check polarity before connecting devices, in order to avoid potential damage.
- 4. Connect Red lead [Pos. +] and Black lead [Neg. -] to device to be powered.
- 5. LED will illuminate when power is present.

* For CE compliance use a Class 2 Power-Limited Power Source.

Fig. 1



Installing VR1T, VR1TM5, VR2T (Figs. 2-4, pg. 2):

1. Mount unit in proximity to the device. Affix one side of velcro (supplied) to unit and place the second side of the velcro in the desired location.

Fig. 3

Altronix®

0 0 0 0

0

24VDC

Input

 $\bigcirc \bigcirc \bigcirc$

12VDC Output

Power

I FD

- 2. Connect 24VAC transformer or 24VDC source* to the terminals marked [24VDC/24VAC Input].
- 3. Measure output voltage and check polarity before connecting devices, in order to avoid potential damage.
- Connect device to be powered to the terminals marked [+ Output –].
- 5. LED will illuminate when power is present.
 - * For CE compliance use a Class 2 Power-Limited Power Source.


Fig. 2 altronix.co Altronix[®] Brooklyn, NY, U.S.A VR1T Voltage Regulator 24VAC/24VDC Input to 12VDC Output @ 1A max. 24VAC/24VDC 12VDC Input + Output CE 0 0 0 0 ĎĎĎ $\bigcirc \bigcirc \bigcirc$ 0 Power 24VAC/VDC LED Input 12VDC Output

Installing VR3T, VR4T (Figs. 5-6, pg. 2):


- 1. Mount unit in proximity to the device. Affix one side of velcro (supplied) to the unit and place the second side of the velcro in the desired location.
- Connect 24VDC source* to the terminals marked [24VDC + Input –].
- 3. Measure output voltage and check polarity before connecting devices, in order to avoid potential damage.
- 4. Connect device to be powered to the terminals marked [- Output +].
- 5. LED will illuminate when power is present.
 - * For CE compliance use a Class 2 Power-Limited Power Source.


Installing VR5T, VR5BT (Figs. 7-8, pg. 2):


- 1. Mount unit in proximity to the device. Use a proper fastener and/or wall anchor when securing unit to the wall.
- 2. Connect 24VAC transformer or 24VDC source* to the terminals marked [Input].
- 3. Measure output voltage and check polarity before connecting devices, in order to avoid potential damage.
- 4. Connect device to be powered to the terminals marked [- OUT +].
- 5. LED will illuminate when power is present.
- 6. For VR5BT *(Fig. 8, pg. 2)* when the use of stand-by batteries is desired, they must be lead acid or gel type. Connect battery to terminals marked [– BAT +].
 - * For CE compliance use a Class 2 Power-Limited Power Source.




Brooklyn, NY, U.S.A









Altronix is not responsible for any typographical errors. Product specifications are subject to change without notice.

140 58th Street, Brooklyn, New York 11220 USA | phone: 718-567-8181 | fax: 718-567-9056 website: www.altronix.com | e-mail: info@altronix.com | Lifetime Warranty IVRseries - Rev. 070709 D06W

